

SHARP

MUSIC SYSTEM FOR iPod®

MODEL

DK-A1H DK-A1H(BK)

OPERATION MANUAL




iPod is a registered trademark of
Apple Computer, Inc.



Thank you for purchasing this SHARP product.
To obtain the best performance from this product, please read this
manual carefully. It will guide you in operating your SHARP product.

The illustrations printed in this operation manual are for the model DK-A1H.



Special notes

WARNINGS

- When the ON/STAND-BY button is set at STAND-BY position, mains voltage is still present inside the unit. When the ON/STAND-BY button is set at STAND-BY position, the unit may be brought into operation by the timer mode or remote control.
- This unit contains no user serviceable parts. Never remove covers unless qualified to do so. This unit contains dangerous voltages, always remove mains plug from the socket before any service operation and when not in use for a long period.
- To prevent fire or shock hazard, do not expose this appliance to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not turn the volume on to full at switch on and listen to music at moderate levels. Excessive sound pressure from earphones and headphones can cause hearing loss.

Note for users in Australia:

Copyright may exist in material you wish to record. Copying or broadcasting such material without permission of the relevant licensees or owners of the copyright is prohibited by law. SHARP is not in a position to authorise the copying or broadcasting of copyright materials and nothing in this OPERATION MANUAL should be implied as giving that authority.

For other countries:


Audio-visual material may consist of copyrighted works which must not be recorded without the authority of the owner of the copyright. Please refer to the relevant laws in your country.

Special Note

Supply of this product does not convey a license nor imply any right to distribute content created with this product in revenue-generating broadcast systems (terrestrial, satellite, cable and/or other distribution channels), revenue-generating streaming applications (via Internet, intranets and/or other networks), other revenue-generating content distribution systems (pay-audio or audio-on-demand applications and the like) or on revenue-generating physical media (compact discs, digital versatile discs, semiconductor chips, hard drives, memory cards and the like). An independent license for such use is required. For details, please visit <http://mp3licensing.com> MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson.

Accessories

Please confirm that the following accessories is included.



Note:

Only the above accessories are included.

Contents


DK-A1H
DK-A1H(BK)

	Page
■ General Information	
Precautions	4
Controls and indicators	5 - 7
■ Preparation for Use	
System connections	8 - 9
Remote control	10
■ Basic Operation	
General control	11
Setting the clock	12
■ iPod	
Listening to the iPod	13 - 15
■ Radio	
Listening to the radio	16 - 17
■ Advanced Features	
Using the Radio Data System (RDS).....	18 - 22
Alarm and sleep operation.....	23 - 24
Enhancing your system	25
■ References	
Troubleshooting chart	26 - 27
Maintenance	27
Specifications	28
WARRANTY	back cover


Precautions

■ General


- Please ensure that the equipment is positioned in a well-ventilated area and ensure that there is at least 10 cm (4") of free space along the sides, top and back of the equipment.




- Use the unit on a firm, level surface free from vibration.



- Keep the unit away from direct sunlight, strong magnetic fields, excessive dust, humidity and electronic/electrical equipment (home computers, facsimiles, etc.) which generate electrical noise.



- Do not place anything on top of the unit.
- Do not expose the unit to moisture, to temperatures higher than 60°C (140°F) or to extremely low temperatures.
- If your system does not work properly, disconnect the AC power lead from the wall socket. Plug the AC power lead back in, and then turn on your system.
- In case of an electrical storm, unplug the unit for safety.




- Do not lift the unit by holding left or right side panel, it may cause the unit damage or broken.



- Hold the AC power plug by the head when removing it from the wall socket, as pulling the lead can damage internal wires.
- The AC power plug is used as disconnect device and shall always remain readily operable.



- **Do not remove the outer cover, as this may result in electric shock. Refer internal service to your local SHARP service facility.**



- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.




- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- Attention should be drawn to the environmental aspects of battery disposal.
- This unit should only be used within the range of 5°C - 35°C (41°F - 95°F).
- The apparatus is designed for use in moderate climate.

Warning:

The voltage used must be the same as that specified on this unit. Using this product with a higher voltage other than that which is specified is dangerous and may result in a fire or other type of accident causing damage. SHARP will not be held responsible for any damage resulting from use of this unit with a voltage other than that which is specified.

■ Volume control



The sound level at a given volume setting depends on speaker efficiency, location, and various other factors. It is advisable to avoid exposure to high volume levels. Do not turn the volume on to full at switch on and listen to music at moderate levels. Excessive sound pressure from earphones and headphones can cause hearing loss.



■ Top panel

	Reference page
1. iPod Dock	14
2. ON/STAND-BY Button	11, 16, 27
3. Clock Button	12
4. iPod Button	13, 14
5. Alarm Indicator	23
6. Auxiliary Button	25
7. Snooze/Dimmer Button	11, 24, 27
8. Tuner Button	16
9. Remote Sensor	10
10. Alarm Button	23
11. Alarm ON/OFF Button	23
12. E Sound/Demo Button	9, 11, 27
13. Play/Pause Button	13, 15
14. Skip Down, Tuner Preset Down Button	12, 15, 17
15. Skip Up, Tuner Preset Up Button	12, 15, 17
16. EQ Button	11
17. Volume Down Button	11
18. Volume Up Button	11

Controls and indicators (continued)



Display

Reference page


1. Alarm Indicator	23
2. Sleep Indicator	24
3. iPod Indicator	13
4. Aux Indicator	25
5. FM Stereo Mode Indicator	16
6. FM Stereo Receiving Indicator	16
7. RDS Indicator	18
8. Summer Time Indicator	12

SHARP		MODEL NO. DK-A1H
MUSIC SYSTEM		
220-240V ~ 50Hz 28W		
FREQUENCY RANGE : FM 87.5 - 108 MHz		
AM 522 - 1,620 kHz		
SERIAL NO.		
SHARP CORPORATION	MADE IN MALAYSIA TSPC-A742AWZZ	

Rear panel

Reference page

1. AM Loop Aerial Terminal	8
2. AM Aerial Earth Terminal	8
3. FM 75 Ohms Aerial Socket	8
4. Auxiliary Input Sockets	25
5. Headphone Socket	25
6. Video Out Socket	9
7. Summer Time Switch	12
8. AC Input	9




■ Remote control

	Reference page
1. Remote Control Transmitter	10
2. Function Button	11
3. On/Stand-by Button	10, 11, 16
4. Volume Up and Down Buttons	11
5. Skip Down, Tuner Preset Down Button	12, 15, 17
6. Play Mode Button	15
7. Tuning Up and Down Buttons	16
8. Memory Button	17, 24
9. Clock Button	12
10. Snooze/Dimmer Button	11, 24
11. Sleep Button	24
12. Alarm Button	23
13. Skip Up, Tuner Preset Up Button	12, 15, 17
14. Display Button	12, 15
15. Play/Pause Button	13, 15
16. E Sound/Demo Button	9, 11
17. Clear Button	17
18. EQ Button	11
19. RDS Display Button	18
20. RDS PTY Button	18
21. RDS ASPM Button	18

Note:

Before using remote control, please remove plastic shield at battery holder.



System connections

Make sure to unplug the AC power lead before any connections.


■ Aerial connection

Supplied FM aerial:

Connect the FM aerial wire to the FM 75 OHMS socket and position the FM aerial wire in the direction where the strongest signal can be received.

Supplied AM loop aerial:

Connect the AM loop aerial to the AM and GND terminals. Position the AM loop aerial for optimum reception. Place the AM loop aerial on a shelf, etc., or attach it to a stand or a wall with screws (not supplied).




Note:

Placing the aerial on the unit or near the AC power lead may cause noise pickup. Place the aerial away from the unit for better reception.

Installing the AM loop aerial:

< Assembling >




< Attaching to the wall >



■ External FM aerial

Use an external FM aerial if you require better reception. Consult your dealer.




Note:

When an external FM aerial is used, disconnect the supplied FM aerial wire.

■ Setting the FM/AM interval

The International Telecommunication Union (ITU) has established that member countries should maintain either a 10 kHz or 9 kHz interval between broadcasting frequencies of AM stations and 100 kHz or 50 kHz for FM stations. The illustration shows the 50/9 kHz zones (regions 1 and 3), and the 100/10 kHz zone (region 2).




This product is not equipped with a span selector. However, it will be adjusted to a 9 kHz AM (50 kHz FM) interval when shipped from the factory.

Before using the unit, be sure to set it to the AM/FM tuning interval (span) used in your area.

To change the AM/FM tuning interval (main unit only):

- 1 During demonstration mode, press the E SOUND/DEMO button to enter the stand-by mode.
- 2 Whilst holding down the SNOOZE/DIMMER button, press the ON/STAND-BY button.



- 3 Within 6 seconds, press the ◀◀ or ▶▶ button to select the interval (span) in your area.

The display switches each time you press the ◀◀ or ▶▶ button.



- 4 Within 6 seconds, press the ▶▶ button.

- The unit will enter the power stand-by mode automatically.

Note:

The AM/FM tuning interval will not change unless you press the ▶▶ button within 6 seconds.


Caution:

- When the unit is left for a few days after the span has been changed and the AC power lead disconnected, the AM span will be automatically returned to 9 kHz (FM span to 50 kHz). If this happens, set the span again.
- When the span is changed, all the memorised stations will be cancelled.
- This operation can not operate during alarm is activated. Deactivate the alarm first. (refer page 23)

■ Connecting iPod to TV

iPod photo and 5th Generation iPod with photo and video can be viewed by connecting to TV/monitor.

If the TV/monitor has a video input, connect it to the VIDEO OUT socket on the rear of the unit.




Note:

Please make sure to set the iPod unit, to either NTSC or PAL to match your TV signal. Please visit Apple's homepage for further information.

■ AC power connection

After checking all the connections have been made correctly, plug the AC power lead of this unit into the wall socket. If you plug in the unit first, the unit will enter the demonstration mode.



Note:


- Unplug the AC power lead from the wall socket if the unit will not be in use for a prolonged period of time.

■ Demonstration mode

The first time the unit is plugged in, the unit will enter the demonstration mode.

To cancel the demonstration mode:

When the unit is in the demonstration mode, press the E SOUND button. The unit will enter the power stand-by mode (low power consumption mode).



To return to the demonstration mode:

When the unit is in the power stand-by mode, press the E SOUND/DEMO button again.

Note:


When the power is on, the E SOUND/DEMO button can be used to select the E SOUND mode.

Remote control


■ Battery installation

This product contains a CR Coin Lithium Battery which contains Perchlorate Material – special handling may apply. California residents, see www.dtsc.ca.gov/hazardouswaste/perchlorate/

- 1 Whilst pushing the locking tab towards the centre of the remote control, slide out the battery holder.



- 2 Remove the old battery from the battery holder, insert the new battery and then slide the battery holder back into the remote control.



Precautions for battery use:

- Remove the battery if the unit will not be used for long periods of time. This will prevent potential damage due to battery leakage.

Caution:

- Do not use rechargeable battery (nickel-cadmium battery, etc.).
- Replace only with the same or equivalent type.
- Installing the battery incorrectly may cause the unit to malfunction.
- Danger of explosion if battery is incorrectly replaced.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

Notes concerning use:


- Replace the battery if the operating distance is reduced or if the operation becomes erratic. Purchase “CR 2025”, coin lithium battery.
- Periodically clean the transmitter on the remote control and the sensor on the unit with a soft cloth.
- Exposing the sensor on the unit to strong light may interfere with operation. Change the lighting or the direction of the unit if this occurs.
- Keep the remote control away from moisture, heat, shock, and vibrations.


■ Test of the remote control

Check the remote control after checking all the connections (see page 8 - 9).

Point the remote control directly at the remote sensor on the unit.

The remote control can be used within the range shown below: Press the ON/STAND-BY button. Does the power turn on? Now, you can enjoy the music.





■ To turn the power on


Press the ON/STAND-BY button to turn the power on.

After use:

Press the ON/STAND-BY button to enter the power stand-by mode or demonstration mode.

■ Illumination light control

Press the SNOOZE/DIMMER button to adjust the brightness of the display and subwoofer illumination light.




■ Volume auto fade-in

If you turn off and on the main unit with the volume set to 27 or higher, the volume starts at 16 and fades in to the last set level.

■ Volume control

Main unit and remote control operation:

Press the VOL (+ or -) button to increase or decrease the volume.




■ E SOUND control

When the E SOUND/DEMO button is pressed, the current mode setting will be displayed. To change the setting, press the E SOUND/DEMO button repeatedly to toggle ON or OFF. When ON is selected, the unit will enter the E SOUND mode and adjust low bass and high frequency automatically according to volume input.



■ Equaliser

When the EQ button is pressed, the current mode setting will be displayed. To change to a different mode, press the EQ button repeatedly until the desired sound mode appears.



■ Function


When the FUNCTION button on remote control is pressed, the current function will change to different mode, press the FUNCTION button repeatedly to select desired function.



Note:

The backup function will protect the memorised function mode for a few days should there be a power failure or the AC power lead becomes disconnected.



Setting the clock



In this example, the clock is set for the 12-hour (12:00 AM) display.

1 Press the CLOCK button for more than 2 seconds.

2 Press the ◀ or ▶ button to select 12-hour or 24-hour display and then press the CLOCK button.




3 Press the ◀ or ▶ button to adjust the hour and then press the CLOCK button.



Press the ◀ or ▶ button once to advance the time by 1 hour. Hold it down to advance continuously.

4 Press the ◀ or ▶ button to adjust the minutes and then press the CLOCK button.



Press the ◀ or ▶ button once to advance the time by 1 minute. Hold it down to change the time in 5-minutes interval.

To confirm the time display:

[When the unit is in the stand-by mode or in demonstration mode.] Press the CLOCK button to enter the clock function.

[When the power is on]

Press DISPLAY button on the remote control to toggle between the function information and clock display.

Notes:

- The clock will continue counting for 8 hours should there be a power failure or the AC power lead becomes disconnected.
- The "CLOCK ADJ" will appear or time will flash to confirm the time display when the AC power supply is restored after a power failure or unplugging the unit after 8 hours. If incorrect, readjust the clock as follows.

To readjust the clock:

Perform "Setting the clock" from step 1 to step 4.


To change the 12-hour or 24-hour display:

- 1 Clear all the programmed contents. [Refer to "Clearing all the memory (reset)" on page 27 for details.]
- 2 Perform "Setting the clock" from step 1.

Summer Time:

The Summer Time switch is located on the rear of the unit.

- 1 Slide the Summer Time switch to +1 to advance the time 1 hour.
- 2 Slide the Summer Time switch to -1 to turn the clock back 1 hour.



Supported iPod models:

- iPod nano (software 1.0 above)
- iPod photo (software 1.0 above)
- iPod mini (software 1.2 above)
- 5th Generation iPod (software 1.0 above) (Dock connector equipped Click Wheel model)
- 4th Generation iPod (software 3.0.2 above) (Dock connector equipped Click Wheel model)
- 3rd Generation iPod (software 2.2 above) (Dock connector equipped Click Wheel model)

Caution:

- Please update your iPod unit to the latest software version before using it. Please visit Apple's homepage to download the latest version for your iPod.

Notes:

- Once the iPod is connected to the unit it will begin charging.
- The iPod unit can not be charged whilst the main unit is in the stand-by mode.

Auto power on function:

When you press any of the following buttons, the unit turns on.

- iPod button (main unit): The unit turns on and the iPod function is activated.
- ► / || button (main unit and remote control): The unit turns on and playback of the last function will start (iPod, TUNER, AUX).

■ iPod adaptor connection

Choose the iPod adaptor that fits your iPod. Your iPod will fit snugly into the correct adaptor. If your iPod is not mentioned below, an iPod adaptor may have been included with your iPod unit.

The number (3-10) shows which iPod fits



iPod Adaptor No.	iPod Description	Capacity
3	iPod mini	4GB & 6GB
4	4G iPod & U2 iPod	20GB
5	4G iPod	40GB
6	iPod photo & Colour U2 iPod	20GB & 30GB
7	iPod photo	40GB & 60GB
6	iPod with colour display	20GB
7	iPod with colour display	60GB
8	iPod nano	2GB & 4GB
9	iPod (10/12/05 w/video)	30GB
10	iPod (10/12/05 w/video)	60GB


Notes:

- iPod nano (Second Generation) is not compatible with the original iPod nano dock adaptor.
- If you have an iPod that does not have an iPod connector, you can use an audio cable to connect it to the AUX IN sockets.


Listening to the iPod (continued)

■ To insert iPod adaptor

1. Push the iPod sliding door until end.



2. Insert the iPod adaptor into unit and connect your iPod.




■ To remove iPod adaptor

Hold this tip and pull as direction shown to remove adaptor.














■ iPod playback

- 1 Press the ON/STAND-BY button to turn the power on.
- 2 Press the iPod button on main unit once or FUNCTION button on remote control repeatedly to select iPod function.
- 3 Open the iPod terminal door and insert iPod unit in iPod dock of main unit.
 
- 4 Press the ► / || button to start playback.

To disconnect iPod

Simply remove the iPod from the iPod dock. It is safe to do so even during playback.

■ Various iPod functions

Function	Main unit	Remote control	Operation
Play			Press in the pause mode.
Pause			Press in the playback mode.
Track up/down			Press in the playback or pause mode. If you press the button in the pause mode, press the ► / button to start the desired track.
Fast forward/reverse			Press and hold down in the playback mode. Release the button to resume playback.
Display	—		iPod back light ON.
Repeat	—		Press to toggle repeat mode.
Shuffle	—		Press and hold down to toggle shuffle mode.

iPod operation

The operations described below depend on the generation iPod you are using.

System on operation

When the main unit is powered on, the iPod unit will automatically power on when docked in the unit (including alarm function).

* Invalid for 3rd iPod Generation.

System off (stand-by operation)

When the main unit is turned to stand-by mode, the docked iPod unit will automatically turn to stand-by mode.


iPod playback detection function

Once play button on iPod unit is pressed, the unit will automatically change to iPod function overriding the previous function selected.

Caution:

- Unplug all accessories for the iPod before inserting it into the iPod dock.

Listening to the radio



Auto power on function:

When you press any of the following buttons, the unit turns on.

- TUNER button (main unit): The unit turns on and the TUNER function is activated.
- ►/|| button (main unit and remote control): The unit turns on and playback of the last function starts (iPod, TUNER, AUX).

Note:

This product can receive FM stereo/FM monaural and AM monaural broadcasts. AM stereo broadcasts will not be played in stereo.

■ Tuning

- 1 Press the ON/STAND-BY button to turn the power on.
- 2 Press the TUNER button on main unit or FUNCTION button on remote control repeatedly to select the desired frequency band (FM or AM).
- 3 Press the TUNING (▼ or ▲) button on remote control to tune in to the desired station.

Manual tuning:

Press the TUNING (▼ or ▲) button as many times as required to tune in to the desired station.

Auto tuning:

When the TUNING (▼ or ▲) button is pressed for more than 0.5 seconds, scanning will start automatically and the tuner will stop at the first receivable broadcast station.

Notes:

- When radio interference occurs, auto scan tuning may stop automatically at that point.
- Auto scan tuning will skip weak signal stations.
- To stop the auto tuning, press the TUNING (▼ or ▲) button again.
- When an RDS (Radio Data System) station is tuned in, the frequency will be displayed first, and then the RDS indicator will light up. Finally, the station name will appear.
- Full auto tuning can be achieved for RDS stations "ASPM", see page 19.

To receive an FM stereo transmission:

Press the TUNER button (main unit) or FUNCTION button (remote control) to select stereo mode and "ST" indicator will be displayed.

- "∞" will appear when an FM broadcast is in stereo.
- If the FM reception is weak, press the TUNER button (main unit) or FUNCTION button (remote control) to extinguish the "ST" indicator. The reception changes to monaural, and the sound becomes clearer.

FM stereo mode indicator



FM stereo receiving indicator

■ Memorising a station

You can store 40 AM and FM stations in memory and recall them at the push of a button. (Preset tuning)

1 Perform steps 1 - 3 in "Tuning" on page 16.

2 Press the MEMORY button on remote control to enter the preset tuning saving mode.



3 Within 1 minute, press the ◀◀ or ▶▶ button to select the preset channel number.

Store the stations in memory, in order, starting with preset channel 1.

4 Within 1 minute, press the MEMORY button on remote control to store that station in memory.



If the preset number indicators disappear before the station is memorised, repeat the operation from step 2.

5 Repeat steps 1 - 4 to set other stations, or to change a preset station.

When a new station is stored in memory, the station previously memorised for that preset channel number will be erased.

Note:

The backup function protects the memorised stations for a few days should there be a power failure or the AC power lead becomes disconnected.


■ To recall a memorised station

Press the ◀◀ or ▶▶ button for less than 0.5 seconds to select the desired station.

■ To scan the preset stations

The stations saved in memory can be scanned automatically. (Preset memory scan)

- 1 Press the ◀◀ or ▶▶ button for more than 0.5 seconds. The preset number will flash and the programmed stations will be tuned in sequentially, for 5 seconds each.
- 2 Press the ◀◀ or ▶▶ button again when the desired station is located.



■ To erase entire preset memory

- 1 Press and hold the CLEAR button on remote control for more than 3 seconds. "TUN CLEAR" will be displayed.
- 2 Within 10 seconds, press the MEMORY button on remote control. "COMPLETE" will be displayed.




Using the Radio Data System (RDS)

RDS is a broadcasting service which a growing number of FM stations provide. These FM stations send additional signals along with their regular programme signals. They send their station names, and information about the type of programme such as sport, music, etc.

When tuned to an RDS station, "RDS" and the station name will be displayed.





You can control the RDS by using the buttons on the remote control only.




Information provided by RDS


Each time the RDS DISPLAY button is pressed, the display will switch as follows:



When you are tuning in to a station other than an RDS station or to an RDS station which sends weak signal, the display will change in the following order:



Note that pressing DISPLAY button will change tuner information to clock display.
Example:



■ Using the Auto Station Programme Memory (ASPM)

Whilst in the ASPM operation mode, the tuner will automatically search for new RDS stations. Up to 40 stations can be stored.

If you have already stored some stations in memory, the number of new stations you can store will be less.

1 Press the TUNER button on main unit or FUNCTION button on remote control repeatedly to select the FM band.

2 Press and hold down the RDS ASPM button on the remote control for at least 3 seconds.

1 After "ASPM" has flashed for about 4 seconds, scanning will start (87.50 - 108.00 MHz).



2 When an RDS station is found, "RDS" will appear for a short time and the station will be stored in memory.



3 After scanning, the number of stations stored in memory will be displayed for 4 seconds, and then "END" will appear for 4 seconds.



To stop the ASPM operation before it is complete:

Press the RDS ASPM button whilst it is scanning for stations.

The stations which are already stored in memory will be kept there.

Notes:

- If the same station is broadcasting on different frequencies, the strongest frequency will be stored in memory.
- Any station which has the same frequency as one stored in memory will not be stored.
- If 40 stations have already been stored in memory, the scan will be aborted. If you want to redo the ASPM operation, erase the preset memory.
- If no stations have been stored in memory, "END" will appear for about 4 seconds.
- If the RDS signals are very weak, station names may not be stored in memory.

To store a station name again if the wrong name was stored in memory:

It may be impossible to store station names in memory using the ASPM function if there is lots of noise or if the signal is too weak. In this case, perform as follows.

- 1 Press the ◀◀ or ▶▶ button to check whether the names are correct.
- 2 If you find a wrong name during receiving the station, wait until the correct name will be displayed. And then press the MEMORY button.
- 3 Within 1 minute, press the MEMORY button whilst the preset channel number is flashing.
 - The new station name has been stored in memory correctly.

Using the Radio Data System (RDS) (continued)

Notes:

- The same station name can be stored in different channels.
- In a certain area or during certain time periods, the station names may temporarily be different.

■ Notes for RDS operation

If any of the following events occur, it does not mean that the unit is faulty:

- “PS”, “NO PS” and a station name appear alternately, and the unit does not operate properly.
- If a particular station is not broadcasting properly or a station is conducting tests, the RDS reception function may not work properly.
- When you receive an RDS station whose signal is too weak, information like the station name may not be displayed.
- “NO PS”, “NO PTY” or “NO RT” will flash for about 5 seconds, and then the frequency will be displayed.

Notes for radio text:

- The first 9 characters of the radio text will appear for 4 seconds and then they will scroll across the display.
- If you tune in to an RDS station which is not broadcasting any radio text, “NO RT” will be displayed when you switch to the radio text position.


■ To recall stations in memory

To specify programmed types and select stations (PTY search):

You can search a station by specifying the programme type (news, sports, traffic programme, etc. ... see pages 21 - 22) from the stations in memory.

1 Press the TUNER button on main unit or FUNCTION button on remote control repeatedly to select the FM band.

2 Press the RDS PTY button on the remote control.




“SELECT” and “PTY TI” will appear alternately for about 6 seconds.

3 Within 6 seconds, press the ◀◀ or ▶▶ button to select the programme type.



Each time the button is pressed, the programme type will appear. If the button is held down for more than 0.5 seconds, the programme type will appear continuously.

4 Whilst the selected programme type is flashing (within 6 seconds), press the PTY button on remote control.



After the selected programme type has been lit for 2 seconds, “SEARCH” will appear, and the search operation will start.

Notes:

- If the display has stopped flashing, start again from step 2. If the unit finds a desired programme type, the corresponding channel number will flash for about 4 seconds, and then the station name will flash for 7 seconds, which will remain lit.
- If you want to listen to the same programme type of another station, press the RDS PTY button whilst the channel number or station name is flashing. The unit will look for the next station.
- If no station can be found, "NOT FOUND" will appear for 4 seconds.

To specify station names and select stations manually:

You can select a station by specifying the name (BBC R1, BBC R2, etc.) from the stations stored in memory.

Before starting this operation, you must store one or more station names in memory.

- 1 Press the TUNER button to select the FM band.
- 2 Press the ◀◀ or ▶▶ button on the remote control to select a desired station.
- 3 The station name will be displayed for 3 seconds. Then the display will change.

Descriptions of the PTY (Programme Type) codes, TP (Traffic Programme) and TA (Traffic Announcement).

You can search for and receive the following PTY, TP and TA signals.

NEWS	Short accounts of facts, events and publicly expressed views, reportage and actuality.
AFFAIRS	Topical programme expanding or enlarging upon the news, generally in different presentation style or concept, including debate, or analysis.
INFO	Programmes whose purpose is to impart advice in the widest sense.
SPORT	Programme concerned with any aspect of sport.
EDUCATE	Programme intended primarily to educate, of which the formal element is fundamental.
DRAMA	All radio plays and serials.
CULTURE	Programmes concerned with any aspect of national or regional culture, including language, theatre, etc.
SCIENCE	Programmes about the natural sciences and technology.
VARIED	Used for mainly speech-based programmes usually of light-entertainment nature, not covered by other categories. Examples include: quizzes, panel games, personality interviews.
POP M	Commercial music, which would generally be considered to be of current popular appeal, often featuring in current or recent record sales charts.
ROCK M	Contemporary modern music, usually written and performed by young musicians.
EASY M	Current contemporary music considered to be "easy-listening", as opposed to Pop, Rock or Classical, or one of the specialised music styles, Jazz, Folk or Country. Music in this category is often but not always, vocal, and usually of short duration.

Using the Radio Data System (RDS) (continued)

LIGHT M	Classical music for general, rather than specialist appreciation. Examples of music in this category are instrumental music, and vocal or choral works.
CLASSICS	Performances of major orchestral works, symphonies, chamber music, etc., and including Grand Opera.
OTHER M	Musical styles not fitting into any of the other categories. Particularly used for specialist music of which Rhythm & Blues and Reggae are examples.
WEATHER	Weather reports and forecasts and meteorological information.
FINANCE	Stock Market reports, commerce, trading, etc.
CHILDREN	For programmes targeted at a young audience, primarily for entertainment and interest, rather than where the objective is to educate.
SOCIAL	Programmes about people and things that influence them individually or in groups. Includes: sociology, history, geography, psychology and society.
RELIGION	Any aspect of beliefs and faiths, involving a God or Gods, the nature of existence and ethics.
PHONE IN	Involving members of the public expressing their views either by phone or at a public forum.
TRAVEL	Features and programmes concerned with travel to near and far destinations, package tours and travel ideas and opportunities. Not for use for announcements about problems, delays, or roadworks affecting immediate travel where TP/TA should be used.
LEISURE	Programmes concerned with recreational activities in which the listener might participate. Examples include, Gardening, Fishing, Antique collecting, Cooking, Food & Wine, etc.
JAZZ	Polyphonic, syncopated music characterised by improvisation.

COUNTRY	Songs which originate from, or continue the musical tradition of the American Southern States. Characterised by a straightforward melody and narrative story line.
NATION M	Current Popular Music of the Nation or Region in that country's language, as opposed to International "Pop" which is usually US or UK inspired and in English.
OLDIES	Music from the so-called "golden age" of popular music.
FOLK M	Music which has its roots in the musical culture of a particular nation, usually played on acoustic instruments. The narrative or story may be based on historical events or people.
DOCUMENT	Programme concerned with factual matters, presented in an investigative style.
TEST	Broadcast when testing emergency broadcast equipment or receivers.
ALARM !	Emergency announcement made under exceptional circumstances to give warning of events causing danger of a general nature.
NONE	No programme type (receive only).
TP	Broadcasts which carry traffic announcements.
TA	Traffic announcements are being broadcast.

Alarm and sleep operation

■ Alarm

The unit turns on and play desired source (iPod, TUNER or AUX) or Buzzer sound for 30 minutes.

Before setting the alarm:


- 1 Check that the clock is set to the correct time. (refer page 12)
If it is not set, you cannot use the alarm function.
- 2 For iPod playback: insert iPod to the unit. (refer page 14)
- 3 For TUNER: Set preset memory. (refer page 17)



Setting the alarm content

1 Press and hold the ALARM button for more than 2 seconds.

2 Press the ◀◀ or ▶▶ button to select source or buzzer.



Press the ALARM button.

3 If TUNER is selected, press the ◀◀ or ▶▶ button to select a preset station. Press the ALARM button.

**4 Press the ◀◀ or ▶▶ button to adjust the hour.
Press the ALARM button.**

**5 Press the ◀◀ or ▶▶ button to adjust the minute.
Press the ALARM button.**

**6 If other than BUZZER is selected in step 2, press the ◀◀ or ▶▶ or VOL (+ or -) button to select volume.
Press the ALARM button.**

Notes:

- If steps 1 - 6 above are done using the remote control, press the ALARM ON/OFF button on main unit to activate the alarm.
- To switch off subwoofer illumination and display in demonstration mode, press the E SOUND/DEMO button.

Changing alarm source only

- After source is selected in step 2, press and hold the ALARM button.
- If TUNER is selected, press and hold the ALARM button after preset station is selected in step 3.
- The time and volume will be automatically set to the previous setting.

Activating and deactivating the alarm

Press the ALARM ON/OFF button on main unit to activate or deactivate the alarm function. When activated:

- During power on, "ALARM" will appear.
- During stand-by mode, ALARM indicator will light up.

Switching off the sound and display

To turn off the sound and display, press either CLOCK button, ON/STAND-BY button or E SOUND/DEMO button.

Checking the alarm setting

- Press the ALARM button.
 - The selected source or buzzer type will blink.
 - The unit will display the alarm time for 3 seconds.
 - During stand-by mode, the display will remain for 6 seconds.
- Example: The time is 10:00 AM and iPod function is selected.



Notes:

- **Buzzer sound will be output from right speaker only.**
- Alarm will not activate during power on mode.
- When iPod is selected in step 2, if iPod unit is not detected during alarm activation, source will automatically change to BUZZER 1.
- When performing alarm using another unit connected to AUX, select AUX in step 2. The unit will turn on and enter the clock function automatically, however, the connected unit to AUX will not turn on or off.
- When the entire preset memory is erased (page 17), source will automatically change to BUZZER 1 even if TUNER is pre-selected (step 2).

Alarm and sleep operation (continued)

■ Snooze function

Once alarm has started, pressing the SNOOZE/DIMMER button will stop alarm for 5 minutes.

Once the snooze time has expired, alarm will continue.

To turn off the alarm function

During alarm or snooze, press the ALARM ON/OFF button to turn it off.

■ Sleep operation

The radio and iPod can be turned off automatically.

1 Playback the desired sound source.

2 Press the SLEEP button on remote control to select sleep time.

3 Press the MEMORY button on remote control.
"SLEEP" will appear.

4 The unit will enter the clock function automatically after the preset time has elapsed.
The volume will be turned down 1 minute before the sleep operation finishes.

To confirm the remaining sleep time:

- Whilst "SLEEP" is indicated, press the SLEEP button once to select "SLEEP XXX".
"XXX" is sleep remaining time.
- The remaining sleep time is displayed for about 10 seconds.
- You can change the remaining sleep time whilst it is displayed by pressing the SLEEP button (steps 2 - 3).

To cancel the sleep operation:

Press the ON/STAND-BY button whilst "SLEEP" is indicated.

To cancel the sleep operation without setting the unit to the stand-by mode, proceed as follows.


- Whilst "SLEEP" is indicated, press the SLEEP button to select "SLEEP OFF", and press the MEMORY button.

■ To use alarm and sleep operation together

Sleep and alarm:

For example, you can fall asleep listening to the radio and wake up to iPod in the next morning.

- Set the sleep time (see left, steps 1 - 4).
- Whilst the sleep timer is set, set the alarm (steps 1 - 6, page 23).
- Activate the alarm (page 23).



Troubleshooting chart

Many potential problems can be resolved by the owner without calling a service technician.

If something is wrong with this product, check the following before calling your authorised SHARP dealer or service centre.

■ General

Symptom	Possible cause
<ul style="list-style-type: none"> The clock is not set to the correct time. 	<ul style="list-style-type: none"> Is the Summer Time switch set to the correct setting? (Refer to page 12) Did a power failure occur? Reset the clock. (Refer to page 27)
<ul style="list-style-type: none"> When a button is pressed, the unit does not respond. 	<ul style="list-style-type: none"> Set the unit to the power stand-by mode and then turn it back on. If the unit still malfunctions, reset it. (Refer to page 27)
<ul style="list-style-type: none"> No sound is heard. 	<ul style="list-style-type: none"> Is the volume level set to "0"? Are the headphones connected?

■ Remote control

Symptom	Possible cause
<ul style="list-style-type: none"> The remote control does not operate. 	<ul style="list-style-type: none"> Is the AC power lead of the unit plugged in? Is the battery polarity correct? Is the battery dead? Is the distance or angle incorrect? Does the remote control sensor receive strong light?

■ Tuner

Symptom	Possible cause
<ul style="list-style-type: none"> The radio makes unusual noises continuously. 	<ul style="list-style-type: none"> Is the unit placed near the TV or computer? Is the FM aerial or AM loop aerial placed properly? Move the aerial away from the AC power lead if it is located nearby.

■ iPod

Symptom	Possible cause
<ul style="list-style-type: none"> No sound is produced. No image appears on the TV/monitor. 	<ul style="list-style-type: none"> The iPod is not playing. The iPod is not properly connected to the unit. Is the AC power lead of the unit plugged in? The video cable is not properly connected. The TV/monitor's input selection is not properly set.
<ul style="list-style-type: none"> iPod will not charge. 	<ul style="list-style-type: none"> The iPod is not making full contact with the iPod connector. The main unit is in stand-by mode.

■ Condensation

Sudden temperature changes, storage or operation in an extremely humid environment may cause condensation inside the cabinet or on the transmitter on the remote control.

Condensation can cause the unit to malfunction. If this happens, leave the power on until normal playback is possible (about 1 hour). Wipe off any condensation on the transmitter with a soft cloth before operating the unit.

Maintenance

■ If trouble occurs

When this product is subjected to strong external interference (mechanical shock, excessive static electricity, abnormal supply voltage due to lightning, etc.) or if it is operated incorrectly, it may malfunction.

If such a problem occurs, do the following:


- 1 Set the unit to the stand-by mode and turn the power on again.
- 2 If the unit is not restored in the previous operation, unplug and plug in the unit, and then turn the power on.

Note:

If neither operation above restores the unit, clear all the memory by resetting it.

■ Clearing all the memory (reset)

- 1 Press the ON/STAND-BY button to enter the power stand-by mode or demonstration mode.
- 2 Whilst pressing down the SNOOZE/DIMMER button and the E SOUND/DEMO button, press the ON/STAND-BY button until "CLEAR ALL" appears.
- 3 Can be operate on main unit only.



Caution:

This operation will erase all data stored in memory including clock, alarm settings and tuner preset.

■ Before transporting the unit

Remove the iPod from the unit. Then, set the unit to the power stand-by mode. Carrying the unit with iPod left docked might damage both the unit and the iPod.

■ Cleaning the cabinet

Periodically wipe the cabinet with a soft cloth and a diluted soap solution, then with a dry cloth.

Caution:

- Do not use chemicals for cleaning (petrol, paint thinner, etc.). It may damage the cabinet finish.
- Do not apply oil to the inside of the unit. It may cause malfunctions.

Specifications

As part of our policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.

■ General

Power source	AC 220 - 240 V, 50 Hz
Power consumption	Power on: 28 W Power stand-by: 0.6 W (*)
Output power	Front Speaker: RMS: 4 W (2 W + 2 W) (10% T.H.D.) RMS: 4 W (2 W + 2 W) (0.9% T.H.D.)
	Subwoofer: RMS: 10 W (5 W + 5 W) (10% T.H.D.) RMS: 6 W (3 W + 3 W) (0.9% T.H.D.)
Speaker	1-way type light-up speaker system Front Speakers: 6.5 cm (2-1/2") - 12 ohms - Full Range Subwoofer: 10 cm (4") - 8 ohms - Woofer
Speaker maximum input power	Front Speakers: 4W/Channel Subwoofer: 10W/Channel
Speaker rated input power	Front Speakers: 2W/Channel Subwoofer: 5W/Channel
Output terminals	Headphones: 16 - 50 ohms (recommended: 32 ohms) Video output: 1Vp-p
Input terminals	Auxiliary (audio signal): 500 mV/47 k ohms
Dimensions	Width: 400 mm (15-3/4") Height: 145 mm (5-3/4") Depth: 251 mm (9-7/8")
Weight	4.3 kg (9.5 lbs.)

*This power consumption value is obtained when the demonstration mode is cancelled in the power stand-by mode. Refer to page 9 to cancel the demonstration mode.

■ Tuner

Frequency range	FM: 87.5 - 108 MHz AM: 522 - 1,620 kHz
------------------------	---

MEMO

MEMO

SHARP

FOR LOCATION ENQUIRIES WITHIN

AUSTRALIA

REGARDING YOUR LOCAL
SHARP APPROVED SERVICE CENTRE
VISIT OUR WEBSITE AT

www.sharp.net.au

OR CALL SHARP CUSTOMER CARE

1300 135 022

(LOCAL CALL COST APPLY WITHIN AUSTRALIA)

SHARP CORPORATION OF AUSTRALIA PTY LTD

SHARP

FOR LOCATION ENQUIRIES WITHIN

NEW ZEALAND

REGARDING YOUR LOCAL
SHARP APPROVED SERVICE CENTRE
VISIT OUR WEBSITE AT

www.sharp.net.nz

CONTACT YOUR SELLING DEALER/RETAILER
OR CALL

SHARP CUSTOMER SERVICES

TELEPHONE: 09 573 0111

FACSIMILE: 09 573 0113

SHARP CORPORATION OF NEW ZEALAND LIMITED

SPform019(JUNE 2004)

SHARP

WARRANTY

Consumer Electronic Products

Congratulations on Your Purchase!

This Sharp product is warranted against faults in materials and manufacture for a period of twelve(12) months from the date of original purchase.

If service is required during the warranty period, please contact your nearest Sharp Approved Service Centre. These repairs would be carried out at no charge to the owner, subject to the conditions specified herein.

The owner is responsible for any transportation and insurance costs if the product has to be returned for repair.

This warranty does not extend to accessories or defects or injuries caused by or resulting from causes not attributable to faulty parts or the manufacture of the product, including but not limited to, defect or injury caused by or resulting from misuse, abuse, neglect, accidental damage, improper voltage, liquid spillage, vermin infestation, software, or any alterations made to the product which are not authorised by Sharp.

Please retain your sales documentation, as this should be produced to validate a warranty claim.

This warranty is in addition to and in no way limits, varies or excludes any express and implied rights and remedies under any relevant legislation in the country of sale.

IMPORTANT DO NOT RETURN THIS DOCUMENT TO SHARP

For your reference, please enter the particulars of your purchase below and retain, with your purchase documentation.

Model No. _____ Date of Purchase _____

Serial No. _____ Retailer _____

SHARP
SHARP CORPORATION OF
AUSTRALIA PTY., LIMITED
ABN 140 006 039 405
1 Huntington Drive
Huntingwood NSW 2148
SHARP CORPORATION OF
NEW ZEALAND LIMITED
59 Hugo Johnson Drive
Penrose, Auckland
SHARPWA14 (04/01/2004)

IMPORTANT NOTICE: This warranty applies only to products sold in Australia & New Zealand

SHARP

SHARP CORPORATION

TINSEA177AWZZ
07E R MW ①